

## New style FM remote programming details

### ☰ Programming Remote Control (433MHz FM), (DL-8000736)

#### Programming new remote control

1. Push the programming button
2. The LED will flash green twice and stay green
3. Push the remote control, the LED will flash twice
4. Wait for 10 seconds and the green LED will turn red
5. You can now use the remote control

#### Clearing the memory of the receiver

1. Push the programming button for 10 seconds
2. Let go the button and the the green LED will flash until the memory is empty

